




REGISTER A TYPE 3 DECODER ON THE MYLAPS PRACTICE WEBSITE


The TYPE 3 Decoder can directly upload live practice information on the MYLAPS practice website. A computer with Internet connection is necessary to register the decoder. Following steps describe how to register a TYPE 3 Decoder on the MYLAPS Practice website:

- 1) On the TYPE 3 decoder:
Go to the Data Server submenu of the decoder and change/control the setting:

Press the select button  the Data Server Menu appears is highlighted on the display of the decoder




Press the acknowledge button,  Enabled will be highlighted on the display

Press the select button  and scroll down to the Menu MYLAPS Prac code



Press the acknowledge button  and write down the activation code displayed on the screen



When the code is written, press the acknowledge button , the default screen will appear after 10 seconds



2) On the computer with internet connection:

- Go to <http://www.mylaps.com> and register as an Organization (create a login and a password for your organization).
- Log in as an organization and select [Configure Tracks and Decoders for MYLAPS Practice](#).

YOUR RACE RESULTS ONLINE

HOME SEARCH ONLINE REGISTRATION MYLAPS PRACTICE ONLINE SHOP ABOUT MYLAPS HELP LANGUAGE

AMB IDENTIFICATION & TIMING I-T

MyLaps.com

MyLaps.com, Welcome to Mylaps.com!

You have now reached the Organization Section of MyLaps.com. Here you can upload and manage your results at any time.

To go directly to the uploading page click [Here](#). If you are new to uploading, be sure to read the [Upload-instruction](#).

Mylaps.com control-panel

- Upload Results**
 - Upload results to Mylaps.com
 - Manage Your Uploaded Results
- Extra Features**
 - Manage Championships
 - Manage Events for Online Registration
 - Get started with online registration (PDF)
 - Get Results from Mylaps.com Integrated into Your Website
 - Link to Mylaps.com from Your Website
- Live Practice Results**
 - **Configure Tracks and Decoders for MyLaps Practice**
- Account Management**
 - Modify Your Mylaps.com Account
 - Change Your Organization's Logo on MyLaps.com

- On the screen [Configure Tracks and Decoders for MYLAPS Practice](#) select [On the screen Configure Tracks and Decoders for MYLAPS Practice](#) select [Register a new decoder for live timing](#)

YOUR RACE RESULTS ONLINE

HOME SEARCH ONLINE REGISTRATION MYLAPS PRACTICE ONLINE SHOP ABOUT MYLAPS HELP LANGUAGE

AMB IDENTIFICATION & TIMING I-T

MyLaps.com

MyLaps

Mylaps.com
Welcome to Mylaps.com!

Upload
Control Panel
My Results
Account Settings
Logout

Configure Tracks and Decoders for MyLaps Practice

Welcome to Mylaps Live decoder and track management.

From here you can:

- **Register a new decoder for live timing**
- Configure existing tracks and decoders.

To configure an existing track, please pick one from the list below.



- On the screen Register your decoder for Mylaps live select [click here to configure the decoder and the track](#)

Register your decoder for Mylaps live

Welcome to Mylaps Live decoder-registration

This page contains a brief description on how to setup your decoder for use with Mylaps Live.

A complete instruction can be found in this document:
[Connecting your AMB-Decoder to Mylaps Live](#)

- 1. Configure your decoder to connect to the Internet.**
Before your decoder will be able to put the results on Mylaps live, you have to configure it.
To configure your decoder, follow these instructions:
 - Make sure you have downloaded the latest firmware for your decoder. You can download the latest version from the AMB i.t. support website.
 - If your decoder is up to date, you can configure your decoder for Mylaps live by using the easy step-by-step DecoderWizard. If you don't have the DecoderWizard yet, click here to download it.
Important: The DecoderWizard will provide you with an activation code. You will need to write this code down or copy this code to your clipboard in order to continue the registration.
 - In case of questions/troubles:
Consult the full documentation here:
[Connecting your AMB-Decoder to Mylaps Live](#)
If you still experience problems, contact AMB i.t. by phone or e-mail
Our support staff can guide you in setting up and configuring your decoder.
E-mail: support@amb-it.com
Phone (US): +1 678 816 4000
Phone (Europe): +31 (0)23 5291893
Phone (Asia): +81 3 5758 8299
- 2. If you have completed the decoder-setup, click here to configure the decoder and the track.**

- On the screen Mylaps-Live – Registration [Step 1] fill the Activation code (Chapter 1 of this document) of the decoder and click on Next

NOTE: The format of the information is ****_****_****_****

Mylaps Live - registration [Step 1]

On this page you can start registering your decoder for Mylaps live.

To start, enter the activation code for your decoder that was provided by the DecoderWizard:

Activation code:

[Next>>](#)

- On the screen Mylaps-Live – Registration [Step 2] fill the Decoder options , select the Track options and click on Next



YOUR RACE RESULTS ONLINE

HOME SEARCH ONLINE REGISTRATION MYLAPS PRACTICE ONLINE SHOP ABOUT MYLAPS HELP LANGUAGE

AMB IDENTIFICATION & TIMING I-T

MyLaps.com

MyLaps Live - Registration [Step 2]

The activation code is correct.

Decoder information:
Type: Unknown decoder
EA: xxxxxxxxxxxxxxxx

On this page you can enter additional information about the decoder and information of the track on which your decoder is located.

Decoder options

Looptype:

Loop description: (Not required)
Use this for a section-name. Decoder is start of section.

Distance to next loop: km or miles (Not required)

Track options

Configure a new track for this decoder
 Add this decoder to an existing track

Next>>

- On the screen Mylaps-Live – Registration [Step 3] fill the Track options and click on Next

YOUR RACE RESULTS ONLINE

HOME SEARCH ONLINE REGISTRATION MYLAPS PRACTICE ONLINE SHOP ABOUT MYLAPS HELP LANGUAGE

AMB IDENTIFICATION & TIMING I-T

MyLaps.com

MyLaps Live - Registration [Step 3]

On this page you can enter information information about the track on which your decoder(s) is/are located.

Track options

Track name:

Track length: Kilometers

Tracktype: Main-sport:

Minimum laptime: seconds

Maximum laptime: seconds

City:

Country:

Timezone offset: [+ 1:00] Central European Time - Europe/Amsterdam

Story:

Website:

Logo:

Logo: Delete current logo
Select a logo-file to upload. Type must be in .PNG, .BMP, .JPG or .GIF. format.

Make this track visible on .

Next>>

- The registration is completed

YOUR RACE RESULTS ONLINE

HOME SEARCH ONLINE REGISTRATION MYLAPS PRACTICE ONLINE SHOP ABOUT MYLAPS HELP LANGUAGE

AMB IDENTIFICATION & TIMING I-T

MyLaps.com

MyLaps

MyLaps.com
Welcome to Mylaps.com!

Upload
Control Panel
My Results
Account Settings
Logout

Registration Complete

You have succesfully configured your track.
Click here to view passings on your track.
If you want to change or add more track settings, click here.